

FINISH OR
EMR

CHECK FOR MOUNTING
ANGLES BEING FLUSH
WITH TOP OF TRACK FRAME

CHECK FOR DAMAGED
RAIL OR SLIDE
BRACKET

CHECK FOR DAMAGED
OR MISSING LINKAGE
SPRINGS

CHECK FOR DAMAGED
LINKAGE OR AIR CYLINDER

CHECK FOR
PROPER
LUBRICATION

EXCESSIVE SLACK

WHAT MODEL

AWB
AWS

ARE LOCKING
WEDGES FULLY
ENGAGING

FINISH OR
EMR

CHECK FOR DAMAGED
OR CRACKED
COMPONENTS

CHECK FOR LOCKING
WEDGE AND WEDGE
POCKET WEAR

CHECK FOR DAMAGED
OR MISSING LINKAGE
SPRINGS

NO

YES