
Hard to close 3000
While coupling, does the handle retract at all?
NO
YES
Make sure fifth wheel is in open position.
Make sure kingpin as at correct height.
Check for interference between top plate and base mount.
Check for bent pull handle and/or operating handle base.
Check tip of rotating jaw to see if worn, broken or bent.
Check kingpin to see if bent or worn.
Check to see if main spring(s) or jaw spring is missing or damaged.
Check to see if cover plate is bent or broken.
Finish or call Fontaine Parts Connection.